

# A Very Merry Christmas Card

## What You Need:

- => Blank card/envelope set or cardstock
- => Fabric of your choice
- => Silhouette image
- => HeatnBond Ultrahold (Item#3041600F)
- => Scissors
- => Iron
- Optional: Trim, sequins, ribbon & glue



## What You Do:

- 1** Pre-heat dry iron to silk setting. Cut your material and section of HeatnBond to match the size of your silhouette image.
- 2** Place HeatnBond Ultrahold paper side up on wrong side of material. Glide iron across paper side of HeatnBond Ultrahold lightly for 1-2 seconds. Allow material to cool. Trace the silhouette image onto the paper side of the HeatnBond Ultrahold and cutout. Peel off paper backing. Adhesive should appear milky in colour. Shiny clear adhesive is a sign of overheating which will cause an insufficient bond, at which point you'll need to reapply HeatnBond Ultrahold.
- 3** Place material right side up in desired position on card and iron for 4-6 seconds (Note: adjust ironing time for heavier materials/using several layers).



- 4** Once cooled, now it's time to add flare to your card. Get creative with ribbon, trim, sequins or fabric embellishments!